



DR. JOHANNES HEIDENHAIN GmbH

Dr.-Johannes-Heidenhain-Straße 5
D-8225 Traunreut, Deutschland
☎ Allg. Service (086669) 31-1272
☎ TNC-Service (086669) 31-1446
FAX (086669) 9899

Operating Instructions

POSITIP 850 For Milling



Items Supplied

- POSITIP 850 Display Unit for 4 Axes
- Power Cable
- Operating Instructions
- Certificate of Inspection

Optional

- Connector, 25-pole, for D-subminiature socket X41 (EXT)
- external functions (Id.-Nr. 249154ZY)
- Data transfer cable, 25-pole, for D-subminiature socket X31 data output (Id.-Nr. 24286901)
- KT 110 Edge Finder (Id.-Nr. 25102101)
- Angle bracket (Id.-Nr. 25826101)


Manufacturer's Certificate

We hereby certify that the above unit is radioshielded in accordance with the German official register decree 1046/1984. The German postal authorities have been notified of the issuance of this unit and have been granted admission for examination of the series regarding compliance with the regulations.

Selecting Milling/Turning



As delivered, the POSITIP 850 can be set up for **either** milling or turning applications. The following screen appears after the **first** power-up:



After pressing the  key, the program for milling is permanently set (i. e., is not affected by power interruptions), and this screen display cannot be accessed again. Selection of the turning function is then only possible via parameter P99.0 "Milling, Turning".

Contents

Page

General Information

G1

Working with the POSITIP 850 For Milling

W1

Installation

1	Connections and Controls (Rear of Unit)	I1
2	Mounting the POSITIP 850	I2
3	Connecting Linear and Angle Encoders	I2
4	Connecting the KT 110 Edge Finder	I3
5	Power Connection	I3
6	Switch-On and Function Check	I3
7	Optimizing the Parameters	I4

Technical Description

1	Parameters	T1
1.1	User Parameters	T1
1.1.1	Changing User Parameters	T2
1.1.2	Overview of User Parameters	T4
1.2	Operating Parameters	T5
1.2.1	Accessing the Operating Parameters	T5
1.2.2	Configuring the User Parameters	T7
1.2.3	Presetting the User Parameters	T9
1.2.4	Overview of Operating Parameters	T10
1.3	Tables	T14
1.3.1	Display Step, Signal Period and Subdivision	T14
1.3.2	Factor for Linear Encoders	T14
1.3.2	Display Step, Line Count and Subdivision Factor	T14
1.3.3	for Angle Encoders	T14
1.3.3	Distance-Coded Reference Marks	T15
1.4	Parameter Description	T16
1.4.1	User Parameters	T16
1.4.2	Operating Parameters P	T17
2	RS-232-C/V.24 Data Interface	T21
2.1	Definition of the RS-232-C/V.24 Interface	T21
2.2	Pin Layout/Signal Description	T21
2.3	Connection of External Units (Wiring)	T22
2.4	Data Transfer Rate (Baud Rate)	T23
2.5	Data Format	T23
3	Data Transfer	T24
3.1	Measured Value Output	T25
3.1.1	Storage Via RS-232-C Interface	T25
3.1.2	Storage Via External Functions	T26
3.1.3	Sequence of Character Output	T27
3.2	External Input/Output of Programs	T29
3.3	Input/Output of Operating Parameters	T29

Contents

Page

4	External Functions	T30
4.1	Pin Layout X41 (EXT)	T30
4.2	(25-pole D-Subminiature Socket)	T30
4.3	External Zero Reset	T30
4.3	Storage (Pulse, Contact)	T31
4.4	Zero Crossover Signal	T31
4.5	EMERGENCY STOP Signal	T31
5	Linear and Angle Encoders	T32
5.1	Layout of Encoder Flange Sockets X1 – X4	T32
6	Connection of Probe Systems	T33
6.1	Pin Layout X10 (15-pole D-Subminiature Socket)	T35
7	Specifications	T36
8	Dimensions	T38

General Information

The POSITIP 850 is a versatile programmable digital readout designed primarily for milling machines and lathes. POSITIP features easy-to-read displays and images on a 12-inch CRT screen as well as practical functions that provide powerful support to the machine operator. The POSITIP 850 adapts to varying to job requirements through three selectable modes of operation:

BASIC Mode

- **Digital Readout for simple machining tasks**
 - Automatic REF reference mark evaluation
 - Actual position display with up to 20 freely-selectable datum points

EXPERT Mode

- **Digital Readout with expanded scope of functions**
 - Distance-To-Go display with radius compensation
 - Bolt-hole circle
 - Probing functions for the KT 110 Edge Finder or TS 120 Touch Probe System

PROGO Mode


- **Programmable Digital Readout**
 - Storage of up to 20 different programs
 - Easy programming with conversational guidance, sub-programs and program section repeats

In all three modes of operation the POSITIP 850's integrated HELP function provides explanations of the current procedure, screen contents and functions of the individual keys.

Working with the POSITIP 850 For Milling

This part of the Operating Instructions illustrates the most important procedures for operation of the POSITIP 850. For a more detailed explanation of the individual modes of operation and the corresponding procedures, simply call the HELP functions.

Controls and Screen Displays



Symbol behind the display value: Ø: Diameter display
I: Scaling factor active

With these keys you select the datum (1 to 20), the desired tool radius compensation (R-, R0, R+), and the data interface (FE, EXT)

Selection of cutting data calculator, pocket calculator functions and stopwatch functions

All operating modes, procedures, functions of the individual keys, and error messages are explained

For paging through the individual screens

Return to the previous menu or

Return to the main menu

Display user parameters

Switch-On



Before initial switch-on, please read the information in the chapter "Installation".
The power switch is located on the rear panel.

HEIDENHAIN

POSITIP 850

Press any key to continue
or Press HELP key

▶ Press any key.

Adjust brightness if necessary (control on rear panel)

MODE: BASIC

Pass over reference marks

X-RKIS
Y-RKIS
Z-RKIS
W-RKIS

NO REF
Mode of Op.

POSITIP is in the mode of operation which was last selected (in this case BASIC).

▶ Switch to a different mode of operation:

Press

Mode of Op.

and select desired mode.

On the screen the message appears:

Pass over reference marks

▶ Working in REF mode:
Traverse the reference marks

▶ Otherwise:

Press

No Ref

All displays are zeroed, datum points are not in non-volatile storage.

After crossing the reference marks in all axes:

SELECT FUNCTION		EXPERT	
X +	102.425	Actual	REF
Y +	366.316	Posit.	
Z -	31.022	Dist. -	
W +	13.910	To-Go	
		Bolt Circle	
		Probe	

The main menu appears for the selected mode of operation. The abbreviation REF in the entry line indicates REF mode. The position data are referenced to the current datum.



Menu keys permit fast selection from among the individual functions and procedures.



Return to the main menu of the selected mode of operation (EXPERT or PROGO).

Example:

The PROBE: EDGE function has been selected
 ► Select the EXPERT main menu

Press

PROBE: EDGE		REF		EXPERT	
X +	102.425			X-Rx1s	
Y +	366.316			Y-Rx1s	
Z -	31.022			Z-Rx1s	
W +	13.910			W-Rx1s	

L1 L2 L3 L4 L5 L6

POSITIP jumps back into the main menu of the EXPERT mode.
 A new function may now be selected.

SELECT FUNCTION		REF		EXPERT	
X +	102.425			Actual	
Y +	366.316			Dist. -	
Z -	31.022			To-Go	
W +	13.910			Bolt Circle	
				Probe	

L1 L2 L3 L4 L5 L6



Return to the previous menu

Example:

The PROBE: EDGE function has been selected.
 ► Return jump to the previous menu: PROBE

Press

PROBE: EDGE		REF		EXPERT	
X +	102.425			X-Rx1s	
Y +	366.316			Y-Rx1s	
Z -	31.022			Z-Rx1s	
W +	13.910			W-Rx1s	

L1 L2 L3 L4 L5 L6

POSITIP jumps back into the PROBE menu.

PROBE		REF		EXPERT	
X +	102.425			Edge	
Y +	366.316			Center -	
Z -	31.022			Line	
W +	13.910			Circle Center	

L1 L2 L3 L4 L5 L6

Each time you press the key you jump back by one menu level until you reach the main menu of the selected mode of operation.



Paging forward and backwards, selection of work screens and soft key assignment.

Example: Selection of Work Screens

POSITIP is in the **PROGRAM INPUT** main menu.

The symbol indicates the currently-selected page (here, page 1).

► **Select page 2:**

Press

The second page of the **PROGRAM INPUT** main menu has been selected. The symbol now indicates page 2 as current page.

► **Return to page 1**

Press

Display returns to the first page of **PROGRAM INPUT**.



Selection of datum points, tool radius compensation and data transfer protocol.

Example 1: Selection of Datum Points

POSITIP is in the main menu of the **BASIC** mode of operation. Example: Datum I2 has been selected.

► **Select new datum, e.g. I2:**

Press or hold down until datum I2 is selected. Out of 20 possible datums, 6 can be displayed at once.

Example 2: Selection of Tool Radius Compensation

The **DISTANCE-TO-GO** function has been selected. No tool radius compensation has been selected: Display R0

► **Select tool radius compensation, e.g. R+:**

Press

Effective tool radius compensation: R+.

Example 3: Selection of the Data Transfer Protocol

In the **PROGO** operating mode, the function **EXTERNAL OUTPUT** has been selected. The data transfer protocol is set on the FE 401: display FE

► **Set data transfer protocol to EXT, e.g. for printer**

Press

Active data transfer protocol: EXT.

Parameter Input

POSITIP features non-volatile parameter storage: the parameters become effective immediately upon switch-on. The parameters are divided into two groups: user parameters and operating parameters. **User parameters** are parameters that can be changed during operation by pressing the MOD key.

Operating parameters concern machine characteristics and are given a fixed setting. For more information on operating parameters see the "Technical Description" section of these instructions.

Example of User Parameters

DISTANCE-TO-GO		EXPERT	
+0.809	REF	Incr./	Rps.
X - 0.909		Set Nom	Pos. X
Y - 241.162		Set Nom	Pos. Y
Z + 600.000		Set Nom	Pos. Z
M - 3.086		Set Nom	Pos. M
L1 L2 L3 L4 L5 L6		R - 30	R +

The DISTANCE-TO-GO function has been selected.

► Call user parameters

Press

MOD

USER PARAMETERS			
Ball	Scaling	Radius	
Dim.	X	X	
Tool	Scaling	Radius	
Dim.	Y	Y	
Baud	Scaling	Radius	
RS-232C	Z	Z	
Line Fd	Scaling	Radius	
RS-232C	M	M	
Operat.	Scaling	Radius	
Param.	OFF	Decimal	

An overview of available parameters appears on the screen.

► Change parameter:



Select desired column

► Call parameter:



Press soft key

► Depart user parameters

Press

MOD

once again

HELP

The HELP function can guide you through the operation of the POSITIP 850. Think of it as integrated operating instructions. At **any time** during operation you can call up an explanation of the current screen image by pressing the HELP key. The HELP function can also tell you how to proceed when an error message occurs.

Example: Calling the HELP Function

ACTUAL POSITION		BASIC	
-35.48	REF	ZERO	
X + 1.380		Preset	X
Y - 1.334		Preset	Y
Z - 29.270		Preset	Z
M + 11.914		Preset	M
L1 L2 L3 L4 L5 L6			

POSITIP is in the main menu of the BASIC operating mode.

► Call HELP:

Press

HELP

HELP: ACTUAL POSITION
After workpiece setup, set the datum (zero or preset value) for workpiece machining:
All positions are referenced to this point.

ZERO You can zero the axis displays for the current position or preset the displays to any desired values.
1/3

An explanation of ACTUAL POSITION appears on the screen.

A HELP text can consist of several pages. The current page and the total number of pages is displayed at the lower right-hand corner of the screen.

► Page further:



to page forward

Press



to page backwards

► Depart HELP

Press

HELP

POSITIP returns to the original screen.

INFO Functions

The INFO functions can be selected from any menu level by pressing the INFO key. The following functions are then available:

Example: Calling the Cutting Data Calculator

INFO FUNCTIONS

PROGO

REF

Cutting Data

Calc.

Stop-watch

Press Cutting Data

The cutting data calculator for calculation of the spindle speed and feed rate appears on the screen.

Pressing the HELP key displays an explanation of this function.

CUTTING DATA

PROGO

Tool diameter?

Enter

D: 0.000

mm

U: 0

m/min

S: 777777

rpm

S: 777777

rpm

d: 0.000

mm

F: 777777

mm/min

► Depart INFO

Press once more

POSITIP returns to the original screen.

External Program Output

Using the EXTERNAL OUTPUT function in the operating mode PROGO, you can transfer one or all of the programs in the PT 850 to an external storage device via the RS-232-C data interface. Programs can be archived on diskette with the FE 401 Floppy Disk Unit from HEIDENHAIN. Printers used with the PT 850 must have a serial RS-232-C interface (please refer to the Technical Description, section 2.5).

Example: Transferring a Program to the FE 401

SELECT FUNCTION

PROGO

Program Number

Actual Posit.

Extern. Input

Program Input

Dist. To-go

Extern. Output

Teach-In

Single Block

Bolt Circle

Auto-matic

Probe

Clear Program

Press the Extern. Output

The main menu of the PROGO operating mode has been selected.

► Call "External Output"

Press the Extern. Output

The EXTERNAL OUTPUT menu appears on the screen.

► Set the data interface to FE 401

Press ("FE" must appear as negative image)

Selecting "FE" sets the data interface and the correct baud rate for the FE 401 Floppy Disk Unit.

► **FE:** Data transfer rate is 9600 baud, regardless of the baud rate set via MOD.

► **EXT:** The baud rate set via MOD for printer output is in effect.

EXTERNAL OUTPUT

PROGO

Program number?

Start Output

1/ 53

Output ALL PGM

Escape

PT 850 PGM dir

PT 850


FE 401

PGM dir

FF EXT

Output a single program

- Enter program number



Output all programs



If there are programs on the diskette with the same PGM number, they will be written over.

Directory of programs stored in the POSITIP program memory



Directory of programs stored on FE diskettes



Cancel data transfer




External Program Input

Using the EXTERNAL INPUT function in the operating mode PROGO, you can transfer programs from an external storage device into the PT 850 via the RS-232-C data interface. Programs can be archived on diskette with the FE 401 Floppy Disk Unit from HEIDENHAIN.

Computers used with the PT 850 must have a serial RS-232-C interface (for the data format, please refer to the Technical Description, section 2.5).

Example: Loading a Program from the FE 401



The main menu of the PROGO operating mode has been selected.

► Call "External Input"

Press the Extern Input

The EXTERNAL INPUT menu appears on the screen

► Set the data interface to FE 401

Press ('FE' must appear as negative image)

Selecting "FE" sets the data interface and the correct baud rate for the FE 401 Floppy Disk Unit.

► **FE:** Data transfer rate is 9600 baud, regardless of the baud rate set via MOD.

► **EXT:** The baud rate set via MOD for printer output is in effect.

Enter the program number of the program to be transferred. If necessary, call up the directory of programs on the diskette using the soft key FE 401 PGM Dir (see "Program Output").


Start
Input



Start transfer of program from floppy disk unit to
POSITIP.

Installation

1 Connections and Controls (Rear of Unit)



* The buffer batteries (three AA size 1.5 V batteries) serve as a power supply for the program memory. Exchange the batteries if the error message EXCHANGE BUFFER BATTERY appears.

The unit must be switched on during battery exchange to prevent erasure of stored programs.



It is very important that you follow this sequence of steps when installing the unit for the first time.


Do not engage or disengage any connectors while the unit is under power.

2 Mounting the POSTIP 850

- Place the display unit in its intended location. The unit can be fixed laterally to a base surface via its M4 tapped fixing holes (see illustration for dimensions).



An angle bracket for mounting the PT 850 on a table is available from HEIDENHAIN (Id.-Nr. 25826101).



3 Connecting Linear and Angle Encoders

- Connect the encoders for the machine axes to the flange sockets for encoder input on the rear panel (see illustration on page I11). Connect the machine axes to the flange sockets according to the following table:

Machine Axis	Flange Socket	Screen Display
X →	X1 →	X + 0.000
Y →	X2 →	Y + 0.000
Z →	X3 →	Z + 0.000
W →	X4 →	W + 0.000

4 Connecting the KT 110 Edge Finder

- Connect the KT 110 Edge Finder (available as accessory Id.-Nr. 25102101) to the D-subminiature socket X10 on the rear panel.
The PT 850 can also be connected to the TS 120 Touch Probe System (see Technical Description, section 6).

5 Power Connection

- Check whether there is a protective ground for the power connection. An M5 threaded pin on the rear panel provides an additional connection for protective ground.
- Connect power cable to the power input socket at rear of unit and switch on power.

6 Switch-On and Function Check



The unit is adapted to the machine tool by means of parameters. These parameters are described in section 1 of the Technical Description. The unit is delivered with **preset parameters** to facilitate commissioning (see Technical Description, section 1.2.4).

Proceed in the following sequence to commission the machine:

- Switch on power (see section 1).
- Adjust desired screen image brightness with control on rear panel.
- Select desired language. The menu for language selection appears only **once** after initial switch-on.
- Press any key (except the HELP key).
- Choose **BASIC** mode of operation (see Working with the POSTIP).
- Press **NO REF** soft key. You need not traverse over the reference points (ignore error messages).
- Use MOD key and the code number 95148 to access the operating parameters (see Technical Description, section 1.2).
- Optimize operating parameters (see section 7).
- Switch power off and then on again.
- Cross over the reference marks (see Working with the POSTIP).

Error Messages

After the reference marks have been crossed over there should be no error message in the display.

If an error message is displayed, press the HELP key for more information and then correct the error. Switch power off and then on again.

If several errors occur at once you can display the error messages one after the other by repeatedly pressing the CE key.

7 Optimizing the Parameters

You can adapt the functions of the POSITIP to the machine tool by optimizing the parameters. Proceed in the sequence given in the following checklist. Write the axis designations of the connected machine axes onto the checklist and check off each point after you have completed the step.




Parameters which must be frequently changed during machine operation are entered as user parameters (see Technical Description). If the KT 110 Edge Finder or the TS 120 3D-Probe System is connected, the ball diameter must be entered in the user parameters.

Checklist

Checklist	Parameter	Encoder Inputs/Axes			
		X1	X2	X3	X4
		Machine Axes			
► Are the encoders connected in the proper sequence (see section 3)?	P 50.*	☐	☐	☐	☐
► Do the axis designations of the ACTUAL POSITION display match the machine axes? Change if necessary.					
► Check axis definition. The axes are set as linear axes. If a rotary axis is connected (for a rotary table), the axis must be set to "rotary". (The rotary axis display can be switched from degrees to degrees/minutes/seconds via the user parameters).	P 48.*	☐	☐	☐	☐
► Enter parameter value for reference marks (see Technical Description, table 1.3.3).	P 45.*	☐	☐	☐	☐
► Set counting direction of the machine axes according to the "Right Hand Rule". Increasing positive display values must correspond to the positive direction of machine axis traverse in relation to the workpiece.	P 40.*	☐	☐	☐	☐
► Approach a datum on the machine table and set the datum on the POSITIP. Then move the table parallel to the axis and compare the actually traversed length or angle with the value displayed on the POSITIP.	P 41.* P 42.*	☐	☐	☐	☐
► Check display step (see Technical Description, tables 1.3.1 and 1.3.2).	P 43.* (linear) P 44.* (angle) P 49.*	☐	☐	☐	☐
► Set the counting mode of the rotary axes (for rotary tables). (Presetting = 360°).		☐	☐	☐	☐

* The asterisk "*" signifies parameters which are specified according to axis by a number behind the decimal point (e.g. 1.1, 1.2 etc.).

(For parameter descriptions see Technical Description, section 1.4).




1 Parameters



All parameters are in non-volatile storage (i.e., they are not affected by power interruptions). All changes are effective immediately!

User parameters are parameters which must be entered or changed frequently during normal machine operation. Press the MOD key to call the menu for user parameters. To leave the menu, press the MOD key again.

Menu: User Parameters




1.1.1

Changing User Parameters

■ Via soft key


Soft keys are used to change from radius to diameter display, from degrees to degrees/minutes/seconds display and to select scaling factor ON or OFF.

Example: Radius or Diameter Display



■ Changing user parameters via numerical input

Example: Ball Tip Diameter



1.1.2
Overview of
User
Parameters

Selection via MOD key

Function	Axis	Change	Input
Radius/Diameter	X Y Z W	Soft key	—
Degrees Decimal or Degrees/min/sec	X Y Z W	Soft key	—
Scaling Factor	X Y Z W	Numerical input	(0.100000 to 9.999999)
Scaling Factor ON/OFF		Soft key	—
Ball Tip Diameter		Numerical input	(0 to 199.999 mm)
Tool Diameter		Numerical input	± (0 to 1999.999 mm)
Baud Rate RS-232-C		Numerical input	110; 150; 300; 600; 1200; 2400; 4800; 9600; 19200; 38400 baud
Line Feed RS-232-C		Numerical input	(0 to 99)

(For descriptions of user parameters see section 1.4.1)



If “Diameter” or “Scaling Factor ON” have been selected, the following symbols appear behind the display value:

Ø: Diameter display
I: Scaling factor active

1.2
Operating
Parameters

- There are three groups of operating parameters:
- P 1.1 to P 9.0 – configuration of the user parameters
 - P21.1 to P28.0 – presetting of the user parameters
 - P40.1 to P99.0 – operating parameters for machine interface


These configuration and settings are made once during commissioning and then remain fixed.




Operating parameters can only be selected through the code number **95148** and should not be changed by the machine operator. We recommend that you keep a written copy of the entry values for the operating parameters or store them on an external data medium.

1.2.1


Accessing the
Operating
Parameters






Selecting the Operating Parameters

■ Selection via vertical soft arrow keys



OR

■ Selection via GOTO




Changing Operating Parameters

■ Changing operating parameters by entering numerical value




■ Changing operating parameters with the horizontal soft arrow key



1.2.2 Configuring the User Parameters

Pressing the MOD key calls the user parameters to the display. These parameters are located in soft-key fields in a certain arrangement of field positions. The field positions are indicated by the numbers in the illustration below. (Factory presetting as it appears after switch-on.)



The field position of any user parameter can be changed by means of the operating parameters P 1.1 to P 9.0. (Exception: field position 15 – operating parameters.) By entering a position of 0, the selected user parameter can be locked from access.


Changing the Field Position

- First you must gain access to the operating parameters using the procedure described above in point 1.2.1. Then select the desired soft-key field.

Example:

You wish to transfer the parameter in field position 14 to field position 13.


Original Display



Procedure

- Select the parameter in field position 14 (factory preset to P 8.0).
 - Enter the new field position (position 13) with numeric keypad and press the soft key Enter.
- Pressing the key recalls the menu for the user parameters.

New Display



1.2.3 Presetting the User Parameters

The overwritten parameter (Baud RS-232C) can be re-entered into the table as follows:

- Repeat procedure for access to operating parameters and select the overwritten parameter (P 7.0 Baud Rate RS-232C). This parameter has assumed the Position: 0.




Access to user parameters via the MOD key can be locked by entering Position: 0.

Note: Locked user parameters can only be changed via the operating parameters P21.1 to P28.0.

If you wish to transfer the locked user parameter (P 7.0) to the vacant field position 14, then enter the field position 14 for this parameter.

The parameter that was originally in position 13 is now in position 14 and vice versa.

User parameters can also be set with the operating parameters (P21.1 to P28.0). This makes it possible to change locked user parameters. Changing these parameters is effective regardless of whether they are changed in the "User Parameters" menu or the "Operating Parameters" menu.



1.2.4 Overview of Operating Parameters

Function	Parameter	Axis*	Entry**
Radius/Diameter X1	P 1.1	X	1
Radius/Diameter X2	P 1.2	Y	2
Radius/Diameter X3	P 1.3	Z	3
Radius/Diameter X4	P 1.4	W	4
Angle Format	P 2.0		5
Scaling Factor X1	P 3.1	X	6
Scaling Factor X2	P 3.2	Y	7
Scaling Factor X3	P 3.3	Z	8
Scaling Factor X4	P 3.4	W	9
Scaling Factor ON	P 4.0		10
Ball Diameter	P 5.0		11
Tool Diameter	P 6.0		12
Baud Rate RS-232-C	P 7.0		13
Line Feed RS-232-C	P 8.0		14
Mode of Operation	P 9.0		0
Radius/Diameter X1	P 21.1	X	radius, diameter
Radius/Diameter X2	P 21.2	Y	
Radius/Diameter X3	P 21.3	Z	
Radius/Diameter X4	P 21.4	W	
Angle Format	P 22.0		degrees decimal, degrees/min/sec
Scaling Factor X1	P 23.1	X	1.000000 (0.100000 to 9.999999)
Scaling Factor X2	P 23.2	Y	
Scaling Factor X3	P 23.3	Z	
Scaling Factor X4	P 23.4	W	
Scaling Factor ON	P 24.0		OFF, ON
Ball Diameter	P 25.0		10.000 (0 to 199.999 mm)
Tool Diameter	P 26.0		0.000 ± (0 to 1999.999 mm)
Baud Rate RS-232-C	P 27.0		9.600 (110, 150, 300, 600, 1200, 2400, 4800, 9600, 19200, 38400 baud)
Line Feed RS-232-C	P 28.0		1 (0 to 99)

Operating Parameters (cont'd.)

Function	Parameter	Axis*	Entry**
Counting Direction X1	P 40.1	X	normal, inverse
Counting Direction X2	P 40.2	Y	
Counting Direction X3	P 40.3	Z	
Counting Direction X4	P 40.4	W	
Signal Period X1	P 41.1	X	4 µm, 10 µm, 20 µm, 40 µm, 100 µm, 200 µm
Signal Period X2	P 41.2	Y	
Signal Period X3	P 41.3	Z	
Signal Period X4	P 41.4	W	
Line Count X1	P 42.1	X	1800, 3600, 9000, 18000, 36000, 72000
Line Count X2	P 42.2	Y	
Line Count X3	P 42.3	Z	
Line Count X4	P 42.4	W	
Linear Subdivision X1	P 43.1	X	100, 80, 50, 40, 20, 10, 8, 5, 4, 2, 1, 0.8, 0.5, 0.4, 0.2, 0.1 (depends on grating period set)
Linear Subdivision X2	P 43.2	Y	
Linear Subdivision X3	P 43.3	Z	
Linear Subdivision X4	P 43.4	W	
Angle Subdivision X1	P 44.1	X	100, 50, 25, 20, 10, 8, 5, 4, 2.5, 2, 1, 0.4, 0.2 (depends on line count set)
Angle Subdivision X2	P 44.2	Y	
Angle Subdivision X3	P 44.3	Z	
Angle Subdivision X4	P 44.4	W	
Distance Coding X1	P 45.1	X	none, 500, 1000, 2000
Distance Coding X2	P 45.2	Y	
Distance Coding X3	P 45.3	Z	
Distance Coding X4	P 45.4	W	

(For description see section 1.4.2)

* For the sake of simplicity, the axis designations are assumed to be those set in parameter P50.* (X1 = X, X2 = Y, X3 = Z, X4 = W). X1, X2, X3, X4 are the corresponding designations of the encoder inputs (see back of unit).

** Factory presettings are indicated in **bold type**.

Operating Parameters (cont'd.)



Function	Parameter	Axis*	Entry**
Monitoring X1	P 46.1	X	off, on
Monitoring X2	P 46.2	Y	
Monitoring X3	P 46.3	Z	
Monitoring X4	P 46.4	W	
Linear Correction X1	P 47.1	X	± (0 to 99999 µm/m)
Linear Correction X2	P 47.2	Y	
Linear Correction X3	P 47.3	Z	
Linear Correction X4	P 47.4	W	
Axis Definition X1	P 48.1	X	off, linear, rotary
Axis Definition X2	P 48.2	Y	
Axis Definition X3	P 48.3	Z	
Axis Definition X4	P 48.4	W	
Angle Counting Mode X1	P 49.1	X	360°, ±180°, ±∞°
Angle Counting Mode X2	P 49.2	Y	
Angle Counting Mode X3	P 49.3	Z	
Angle Counting Mode X4	P 49.4	W	
Axis Designation X1	P 50.1	X	A, B, C, U, V, W, X, Y, Z
Axis Designation X2	P 50.2	Y	
Axis Designation X3	P 50.3	Z	
Axis Designation X4	P 50.4	W	
Axis Combination	P 51.0		off, 1+4, 2+4, 3+4, 1-4, 2-4, 3-4
Dialog Language	P 52.0		2 languages can be selected (see section 1.4.2)
Bolt Circle Plane	P 53.0		X/Y, Y/Z, Z/X
Mirror Graphics	P 54.0		off, vertical and/or horizontal
Direction of Rotation, Bolt Circle Graphics	P 55.0		normal, inverse
Zero Range X1	P 56.1	X	0 (0 to 99,999 mm)
Zero Range X2	P 56.2	Y	
Zero Range X3	P 56.3	Z	
Zero Range X4	P 56.4	W	

Operating Parameters (cont'd.)



Function	Parameter	Axis*	Entry**
Display Freeze	P 57.0		off, concurrent, stopped
Distance-To-Go Mode	P 58.0		bar, actual value
Sleep Delay	P 59.0		15 5 to 98 min. 99 = no protective standby mode
Counter Application	P 99.0		milling, turning

(For description see section 1.4.2)

- * For the sake of simplicity, the axis designations are assumed to be those set in parameter P50.* (X1 = X, X2 = Y, X3 = Z, X4 = W). X1, X2, X3, X4 are the corresponding designations of the encoder inputs (see back of unit).
- ** Factory presettings are indicated in **bold type**.

1.3 Tables

1.3.1

Display Step, Signal Period and Subdivision Factor for Linear Encoders

Signal Period	4 µm	10 µm	20 µm	40 µm	100 µm	200 µm
Display Step	Subdivision Factor					
0.00005 mm/0.000002 in.	80	—	—	—	—	—
0.0001 mm/0.000005 in.	40	100	—	—	—	—
0.0002 mm/0.00001 in.	20	50	100	—	—	—
0.0005 mm/0.00002 in.	8	20	40	80	—	—
0.001 mm/0.00005 in.	4	10	20	40	100	—
0.002 mm/0.0001 in.	2	5	10	20	50	100
0.005 mm/0.0002 in.	0.8	2	4	8	20	40
0.01 mm/0.0005 in.	0.4	1	2	4	10	20
0.02 mm/0.001 in.	—	0.5	1	2	5	10
0.05 mm/0.002 in.	—	0.2	0.4	0.8	2	4
0.1 mm/0.005 in.	—	0.1	0.2	0.4	1	2

1.3.2

Display Step, Line Count and Subdivision Factor for Angle Encoders

Line Count	72 000	36 000	18 000	9 000	3 600	1 800
Display Step	Subdivision Factor					
Degrees/Decimal	Degrees/Min/Sec					
0.0001°	0°00'01"	50	100	—	—	—
0.0002°	0°00'01"	25	50	100	—	—
0.0005°	0°00'01"	10	20	40	—	—
0.001°	0°00'05"	5	10	20	40	—
0.002°	0°00'05"	2.5	5	10	20	—
0.005°	0°00'10"	1	2	4	8	20
0.01°	0°00'30"	—	—	2	4	10
0.02°	0°01'	—	—	—	5	10
0.05°	0°05'	—	—	—	2	4
0.1°	0°30'	—	—	—	1	2
0.5°	0°30'	—	—	—	—	0.4
1.0°	1°	—	—	—	—	0.2

1.3.3

Distance-Coded Reference Marks

Linear Encoder	Max. Traverse for Recovery of the Datum	Parameter
No distance-coded reference marks	Depends on position of the encoder	P 45.* = none
LS 101C	10 mm	P 45.* = 1000
LS 107C	20 mm	
LS 303C		
LS 403C		
LS 404C		
LS 603C		P 45.* = 2000
LS 704C		
ULS 300C	10 mm (grating period 10 µm) 20 mm (grating period 20 µm)	
LID 311C	20 mm	
LID 351C	20 mm	

Angle Encoder	Max. Rotation for Determination of the Absolute Position	Parameter
No distance-coded reference marks	1 rotation	P 45.* = none
ROD 250C (18 000)	20°	P 45.* = 1000
RON 255C (18 000)		
ROD 700C (18 000)		
ROD 800C (18 000)		
ROD 700C (36 000)	10°	
ROD 800C (36 000)		
ROD 700C (9 000)	20°	P 45.* = 500

1.4 Parameter Description

1.4.1 User Parameters

Radius/ Diameter

With this parameter you can select radius or diameter display for linear axes.
If you select diameter, the symbol "Ø" will appear behind the display value.

Angle Format

The display for a rotary axis can be switched between degrees decimal and degrees/minutes/seconds.

Scaling Factor

With the scaling factor you can enter a correction to the workpiece to be machined. The correction range is (0.100000 to 9.999999). A scaling factor greater than 1 will enlarge the workpiece, while a scaling factor less than 1 will reduce it. You can enter a separate scaling factor for each axis.

Scaling Factor OFF/ON

By entering scaling factor OFF, all scaling factors are deactivated. When scaling factor ON is entered, the symbol "I" appears behind the display value.

Ball Tip Diameter (Probing)

In the probing edge operating mode the position value must be corrected by the radius of the ball tip.
The entry range for the ball tip diameter of the edge finder is 0 to 199.999 mm.

Tool Diameter

The tool diameter can be entered in the user parameters and in the operating mode **PROGO** (single block, automatic and teach-in). The tool diameter value last entered becomes effective automatically whenever radius compensation is entered.

Baud Rate RS-232-C

With this parameter you can set the data transfer rate (baud rate) for the data interface (see section 2.3).

Line Feeds RS-232-C

With this parameter you can set the number of additional line feeds (blank lines) between values for an external device (maximum of 99 line feeds).

Special Case: Mode of Operation

This parameter is not configured as a user parameter in the factory presetting. With the Mode of Operation parameter you can choose among the **BASIC**, **EXPERT** and **PROGO** modes of operation via the MOD key without switching the unit off.

1.4.2 Operating Parameters P



In the following description, **axis-specific parameters** are indicated by a parameter number with decimal point and asterisk (example: P 1.*).

The asterisk signifies the axis-specific designation after the decimal point (e.g. P 1.1, P 1.2 etc.).

Parameters which are **not axis-specific** are indicated by a **0** behind the decimal point (e.g. P 5.0).

P 1.* to P 9.0

The "User Parameters" menu is configured by entering positions in the operating parameters P 1.* to P 9.0. The user parameters can be configured in any desired sequence within the positions 1-14. **Position: 0** locks the respective parameter from access via the MOD key (see section 1.2.2).

Special Case: Parameter 9.0 Mode of Operation

In order to prevent an inexperienced operator from making mistakes, the mode selection (**BASIC**, **EXPERT**, **PROGO**) should be made accessible immediately after switch-on and then remain unchangeable during machine operation. The parameter P 9.0 is therefore not active as a user parameter (**position = 0**). If parameter P 9.0 is configured as a user parameter, the operating mode can be selected both before and during machining.



With parameters P 1.* to P 8.0 as user parameters, all 14 freely selectable field positions are occupied. If you wish to define parameter P 9.0 as a user parameter, you must overwrite an already occupied user parameter (e.g. parameter 8.0 Line Feed).

P 21.* to P 28.0

User parameters can also be set in the operating parameters (P 21.1 to P 28.0), making it possible to change even locked user parameters. Changing these parameters is effective regardless of whether they are changed in the "User Parameters" or in the "Operating Parameters" menu. (For description, see section 1.4.1.)

P 40.* Counting Direction

P 41.* Signal Period

With parameter P 40.* you can set the counting direction separately for each axis.

The signal period of the connected encoder must be entered in parameter P 41.*.

If linear axis movement is measured using a rotary encoder with nut and spindle, the signal period must be calculated with the following formula:

$$\text{Signal Period [µm]} = \frac{\text{Spindle Pitch [mm]} \cdot 1000}{\text{Line Count}}$$



Line count (P 42.*) and angle subdivision (P 44.*) are necessary only for rotary axes. For linear axes whose traverse is measured via rotary encoders with nut and spindle, the axis must be defined as a linear axis in parameter P 48.*.

P 42.*
Line Count
The line counts of rotary encoders connected to rotary axes must be entered in parameter P 42.*.

P 43.*
Linear Subdivision
The subdivision factor is entered in parameter P 43.*. The subdivision factor determines the display step and depends on the setting of the signal period (see Table 1.3.1).

P 44.*
Angle Subdivision
The angle subdivision determines the display step for rotary axes and depends on the line count setting (see Table 1.3.2).

P 45.*
Distance Coding
Parameter P 45.* defines whether the display unit is to evaluate signals from encoders with single or with distance-coded reference marks. For encoders with single reference marks enter **none** in parameter P 45.*. For distance-coded reference marks the entry value depends on the encoder model (see Table 1.3.3).

P 46.*
Monitoring
With parameter P 46.* on, the corresponding encoder input signal is checked for the following errors:

- excessive traversing speed
- cable break
- measuring signal error

These errors are then indicated in the visual display.

P 47.*
Linear Correction
Machine error can be measured with the aid of a comparator measuring system (e.g. VM 101 from HEIDENHAIN). These errors can be entered in parameter P 47.* as a linear correction factor in parts per million (ppm) measuring length.

Example: Measuring length 620 mm
Value actually measured (e.g. via VM 101) 619.876 mm
Difference = -124 µm
Conversion to 1 m measuring length
-124 µm · 1000 mm
620 mm
Correction factor -200 µm

Linear Compensation	Parameter Input Range
"Lengthening" the encoder	P47: 0 to + 99 999 [µm/m]
"Shortening" the encoder	P47: 0 to - 99 999 [µm/m]

P 48.*
Axis Definition
Parameter P 48.* defines whether the axis input is inhibited (off) or the axis functions as a linear or rotary axis.



For unused encoder inputs enter **off** in parameter P 48.*.

P 49.*
Angle Counting Mode
Parameter P 49.* defines the way in which angular measurements are displayed.
Possible settings: 360°, ± 180°, ± ∞.

P 50.*
Axis Designation
Parameter P 50.* defines the assignment of axis names to inputs.
Possible settings: A, B, C, U, V, W, X, Y, Z.

P 51.0
Axis Combination
Parameter P 51.* permits the following settings:

off: no combination

1+4: Axes X1 and X4 added and displayed on axis X1

2+4: Axes X2 and X4 added and displayed on axis X2

3+4: Axes X3 and X4 added and displayed on axis X3

1-4: Axis X4 subtracted from X1, result displayed on axis X1

2-4: Axis X4 subtracted from X2, result displayed on axis X2

3-4: Axis X4 subtracted from X3, result displayed on axis X3

P 52.0
Dialog Language
The dialog language can be chosen from two available languages. Which two languages are available depends on the program number:

Program No.	Languages
246060–	German English
246061–	French English
246062–	Dutch English
246063–	Italian English
246064–	Spanish English
246065–	Danish English
246066–	Swedish English
246067–	Finnish English
246068–	Turkish English
246069–	German French
246070–	Dutch French

P 53.0
Bold Circle Plane
Parameter P 53.0 defines the working plane for the bolt hole circle function.
Possible settings: X/Y, Y/Z, Z/X

P 54.0
Mirror Graphics

Display of the bolt hole circle graphics can be set in parameter P 54.0 in the case that it deviates from the normal coordinate system.

- off: no mirroring
- ver: the vertical coordinate axis is mirrored
- hor: the horizontal coordinate axis is mirrored
- ve + ho: both coordinate axes are mirrored

When an axis is mirrored, the direction of rotation for hole numbering is changed in the graphics.

P 55.0
Direction of Rotation, Bolt Circle Graphics

Depending on the setting of parameter P 54.0, parameter P 55.0 defines the direction of rotation of the holes in the bolt hole circle graphics.

- normal: direction of rotation (in the graphics) is from the first to the second axis.
- inverted: direction of rotation (in the graphics) is from the second to the first axis.

P 56.*
Zero Range

Parameter P 56.* defines a range around "zero" in which a zero crossover signal will be generated (see External Functions, section 4).

Input range: 0 to 99.999 mm.

P 57.0
Display Freeze

The current measured value is stored and output over the RS-232-C data interface with every storage procedure (CTRL, pulse, contact). The display on the **screen** can be set with parameter P 57.0:

- off: the display is not stopped during a storage signal
- concnrt: the display is stopped only for the duration of the storage signal
- stopped: the display is stopped, but is updated by every storage signal

P 58.0
Distance-To-Go Mode

In the distance-to-go function, the actual value can be displayed instead of the graphic positioning aid.

- bar: graphic positioning aid
- actual value: display of the absolute position in small type beneath the distance-to-go display.

P 59.0
Sleep Delay

Parameter P 59.0 allows input of a delay time (in minutes) for protective standby mode. If no keys are pressed and no axis movements take place for the length of time entered as the delay time, the screen image is reversed. This prevents screen burning.

- 5 – 98: delay time in minutes
- 99: no protective standby mode.

P 99.0
Counter Application

With parameter P 99.0 the POSITP 850 is set up either for milling or for turning.

2 RS-232-C/V.24
Data Interface

POSITP is equipped with a data interface according to EIA standard RS-232-C (CCITT standard V.24).

2.1
Definition of the RS-232-C/V.24 Interface

The data transfer code is ASCII with even parity bit. The RS-232-C data interface is designed for serial data transfer; devices with parallel data interfaces cannot be connected. Levels for TXD and RXD (negative level for "1"):

Logic Level	Working Level
"1": -3 V ... -15 V	-5 V ... -15 V
"0": +3 V ... +15 V	+5 V ... +15 V

2.2
Pin Layout/Signal Description



RS-232-C/V.24 port

Contact No.	Signal	Meaning
1	CHASSIS GND	Protective Ground
2	TXD*	Transmit Data
3	RXD*	Receive Data
4	RTS	Request To Send
5	CTS	Clear To Send
6	DSR	Data Set Ready
7	SIGNAL GND	Signal Ground
8-19		(vacant)
20	DTR	Data Terminal Ready
21-25		(vacant)


* The designations TXD, RXD indicate negative levels for "1".

2.3 Connection of External Units (Wiring)

The connecting cables must be wired in accordance with the type of data device employed. Pin layouts are sometimes non-standard.


Frequently used wiring:

Complete wiring



Signals RTS, CTS, DSR and DTR must have working level "1" (+ 5 to + 15 V) for data transfer.

Simplified wiring



Signals RTS, CTS, DSR and DTR have permanent working level "1" (+5 V to +15 V) due to bridges 4/5 and 6/20.

2.4 Data Transfer Rate (Baud Rate)


The baud rate indicates the number of bits which can be transferred per second.

Peripheral devices must be fully able to process the selected baud rate in order to avoid errors in data transfer. The desired baud rate is selectable under the user parameters (via the MOD key). The selected baud rate must be identical to the baud rate of the peripheral device.



In FE mode (for the FE 401 Floppy Disk Unit from HEIDENHAIN), the data transfer rate is always 9600 baud regardless of the baud rate set via the MOD key.

2.5 Data Format



The connected unit must be set to "even parity" because of the error monitoring employed in this output. A data transfer cable (Id.Nr. 242 869 . .) is available from HEIDENHAIN.

3 Data Transfer

Measured values, part programs and operating parameters can transferred over the PT 850's RS-232-C data interface. The data interface can operate with two different data transfer protocols:

- ▶ External data transfer protocol (EXT) for printers, punching units, readers and other peripherals.
- ▶ FE data transfer protocol (FE) for the HEIDENHAIN FE 401 Floppy Disk Unit or a suitably adapted computer.

	Data Transfer Protocol	Start Data Transfer With
Measured value output	EXT	RS-232-C interface (CTRL B) Ext. functions (pulse, contact)
Program input	*FE or EXT	"EXTERNAL INPUT" menu
Program output	*FE or EXT	"EXTERNAL OUTPUT" menu
Input and output of operating parameters	*FE or EXT	"OPERATING PARAMETERS" menu


* Select FE or EXT protocol via the arrow keys in the corresponding menus.

3.1 Measured Value Output

The current display value can be transferred over the RS-232-C data interface to peripheral equipment such as a printer. After an external storage command, the measured value is output (for a maximum of 4 axes) through an internal buffer. The storage signal can be generated via the RS-232-C interface or via the "external functions".

3.1.1 Storage via RS-232-C Interface

When the control character CTRL B (= STX) is transmitted, a storage signal is generated and the measured value is transmitted over the TXD output of the RS-232-C data interface. The duration of data transfer depends on the selected baud rate, the number of axes and the number of line feeds.



Interruption of Data Transfer

- ▶ The receiving device can interrupt and restart data transfer by
- ▶ Start/stop via the RXD input of the data interface
- DC3 = X OFF = CTRL S: interrupt data transfer
- DC1 = X ON = CTRL Q: resume data transfer
- ▶ Control line CTS
- ▶ After the stop signal CTS or the stop character DC3 has been received, no more than 2 additional characters can be output.

T26 Technical Description

$$t_1 \leq 0.8 \mu s$$

Delay between storage signal and actual storage (pulse)

$$t_1 \leq 4.5 \text{ ms}$$

Delay between storage signal and actual storage (contact)

$$t_e \geq 1.2 \text{ ms}$$

Input signal (pulse)

$$t_e \geq 7 \text{ ms}$$


Input signal (contact)

$$t_2 \geq 30 \text{ ms} + (5 \text{ ms} \times N)$$

$$t_3 \geq 0 \text{ ms}$$

$$t_0 = \frac{176 \times M + (L \times 11)}{\text{Baud rate}} s$$


L = Number of line feeds
M = Number of axes
N = Number of rotary axes (degrees/min/sec)



Technical Description T27


Depending on the axis definition, the characters for measured value output are generated in the following order:

Output




- * In the "distance-to-go" function,
- for radius display a lower-case r is output
- for diameter display a lower-case d is output

Output



* In the "distance-to-go" function, a lower-case w is output for angular measurement.

(Example for rotary axis/degree-minutes-seconds display)



* In the "distance-to-go" function, a lower-case w is output for angular measurement.



If the linear or angle encoder is defective, no display values are output. For the algebraic sign and the display value, question marks "?" are output.

3.2

External Input/Output of Programs

3.3

Input/Output of Operating Parameters

In the PROGO mode of operation, it is possible to read programs into or out of POSITIP over the RS-232-C data interface (see Working with the POSITIP 850).

Operating parameters can be input and output over the RS-232-C data interface. Printers connected to the PT 850 must be equipped with a serial RS-232-C interface (for the data format see the Technical Description, section 2.5).

Programs and operating parameters with the same program number can be stored with the FE 401 Floppy Disk Unit from HEIDENHAIN. When loading operating parameters, POSITIP automatically generates program number 850 unless a different number is entered.



Sequence:

- ▶ Select operating parameter (see section 1.2)
- ▶ Select page 2 (menu for parameter input/output)
- ▶ Set interface to FE (FE 401 Floppy Disk Unit) or EXT (for printer or other peripheral device).

In FE mode, the data transfer rate is always 9600 baud, independent of the baud rate set via MOD. When EXT is selected, the baud rate set via MOD for printer output is effective.



Operating parameters are read out with program number 850.



Operating parameters with program number 850 are read in.



If you do not wish to input or output the operating parameters with program number 850, then the desired program number must be entered before pressing the "Param. Output" and "Param. Input" soft keys.



Displays the program directory of the FE 401. During read-in of the directory, the dialog Reading FE Directory¹ is displayed.



Data transfer is terminated.

4 External Functions

4.1

Pin Layout X41 (EXT) (25-pole D-Subminiature Socket)

Pin	Assignment	Duration of pulse/ contact closing
1/10	0 V	
2	E Set axis 1 to zero	$t \geq 100$ ms
3	E Set axis 2 to zero	$t \geq 100$ ms
4	E Set axis 3 to zero	$t \geq 100$ ms
5	E Set axis 4 to zero	$t \geq 100$ ms
14	A Zero crossover axis 1	
15	A Zero crossover axis 2	
16	A Zero crossover axis 3	
17	A Zero crossover axis 4	
21	A EMERGENCY STOP	
22	E Storage pulse	$t \geq 1.2$ μ s
23	E Storage contact	$t \geq 7$ ms

E = Input
A = Output

4.2

External Zero

Reset

The inputs (pins 2, 3, 4, 5) are active LOW (open = high level).
 $U_{eH} \geq 3.9$ V (max. 15 V)
 $U_{eL} \leq 0.9$ V at $-I_{eL} \leq 6$ mA
 Switching via TTL components (e.g. SN 74LSXX) is made possible by an internal **1 k Ω** pull-up resistor. Contact closing against 0 V (pin 1 or 10) clears display of the corresponding axis.



External zero reset is only possible during display of actual position.

4.3

Storage (Pulse, Contact)

Contact closing against 0 V (pin 1 or 10) causes a storage signal to be generated and a measured value to be output over the RS-232-C data interface (see section 3.1.2).

4.4

Zero Crossover Signal

A zero crossover signal is produced when the display value of the corresponding axis is zero. A zero recognition range (0 to 99.999 mm) can be entered in parameter P 56 *. If the zero recognition range is moved over quickly, signal duration is approximately 180 ms.

Technical Data

Permissible Load Types

Open-collector output
 Zero crossover signal active HIGH (open-collector transistor inhibited).
 Resistive load
 Inductive load only with quenching diode
 High level output voltage $U_{oH} \leq 32$ V
 (32 V = absolute maximum value of the voltage applied over external resistor or relay)
 Low level output voltage $U_{oL} \leq 0.4$ V at $I_{oL} \leq 100$ mA
 Low level output current $I_{oL} \leq 100$ mA
 (100 mA = absolute maximum value)
 Signal triggering delay $t_{an} = 60 \pm 20$ ms
 Signal duration $t_s = 180$ ms

4.5

EMERGENCY STOP Signal

Technical Data

Permissible Load Types

If a critical error occurs within POSITIP, the EMERGENCY STOP signal is sent over an open-collector output.
 Open-collector output
 EMERGENCY STOP signal active HIGH (open-collector transistor inhibited).
 Resistive load
 Inductive load only with quenching diode
 High level output voltage $U_{oH} \leq 32$ V
 (32 V = absolute maximum value of the voltage applied over external resistor or relay)
 Low level output voltage $U_{oL} \leq 0.4$ V at $I_{oL} \leq 100$ mA
 Low level output current $I_{oL} \leq 100$ mA
 (100 mA = absolute maximum value)
 Signal triggering delay $t_{an} \leq 50$ ms

5 Linear and Angle Encoders

All HEIDENHAIN linear encoders with sinusoidal scanning signals and single or distance-coded reference marks can be connected to POSITIP.

Possible signal periods for linear encoders:

4, 10, 20, 40, 100 and 200 μm

Possible line counts for rotary and angle encoders:

1800, 3600, 9000, 18 000, 36 000 and 72 000

The display step is adjusted to the signal period of the connected linear encoder via parameter P 43. * Subdivision. For rotary axes the display step is adjusted to the line count of the connected rotary/angle encoder via parameter P 44. * Angle Subdivision (see section 1.4).

5.1 Layout of Encoder Flange Sockets X1 – X4

Contact Designation	3	4	1	2	5	6	7	8	9
	+	–	+	–	+	–	+	–	
Assignment	Lamp	U_1	Measuring signal (0° el.)	I_{a1}	Measuring signal (90° el.)	I_{a2}	Reference signal	I_{a0}	Shielding

6 Connection of Probe Systems

KT 110 Edge Finder


Technical Data

The PT 850 has been factory-prepared for connection of the HEIDENHAIN KT 110 2D-Edge Finder and the TS 120 3D-Probe System. In the **EXPERT** and **PROGO** modes of operation, the PT 850 can utilize its software for evaluation of the scanning signals. Select the **PROBE** menu with the function "Probe". The **HELP** key calls up the appropriate **HELP** screens with information and guidance on using this menu.

The KT 110 2D-Edge Finder is used for probing electrically conductive materials. The KT 110 is inserted into a 20 mm collet. Connection is via the X10 D-subminiature socket on the rear panel of the PT 850.

Minimum duration of scanning signal: $t \geq 5 \mu\text{s}$
Interval between two probes: $t \geq 100 \text{ ms}$
For a complete technical description, please refer to the operating instructions for the KT 110.

Basic Circuit Diagram



Output voltage of edge finder: $U_{KT} = 3 \text{ V}$
Input current (assumed value): $I_a = 1 \text{ mA}$


On-state voltage at optocoupler (assumed value): $U_b = 1.5 \text{ V}$

TS 120 Touch Probe System

The TS 120 Triggering 3D Touch Probe System for HEIDENHAIN controls can be connected via a cable adapter to the X 10 D-subminiature socket on the rear of the unit. The material of the workpiece to be scanned must be electrically non-conducting. The stylus can deflect in the directions $\pm X$, $\pm Y$, and $\pm Z$. Upon stylus deflection, the TS 120 generates two triggering signals for differential line transmission.

Technical Data TS 120

The stylus can be deflected beyond the triggering point. The maximum stylus deflection in both X/Y direction and in Z direction is 20 mm (when the standard 47 mm stylus is used). Various stylus lengths available
Various ball diameters available
Triggering signals: TTL square-wave pulses
For a complete technical description, please refer to the TS 120 operating instructions.



6.1 Pin Layout X10 (15-pole D-Subminiature Socket)

Pin	Assignment	Probe System
1	Internal shield	KT 110/TS 120
3	Standby signal	TS 120
5	+ 15 V	TS 120
6	+ 5 V	TS 120
8	0 V	KT 110/TS 120
9	Triggering signal	TS 120
10	Triggering signal	TS 120
14	KT +	KT 110
15	KT -	KT 110

7 Specifications POSITIP 850 For Milling


Mechanical Data	
Housing	Tabletop model, sheet metal chassis; Dimensions (W x H x D) 420 mm x 298 mm x 330 mm (16.5 in. x 11.7 in. x 13.0 in.)
Weight	Approx. 11.7 kg (25.7 lb)
Operating Temperature	0 to 45° C (32 to 113° F)
Storage Temperature	– 30 to 70° C (– 22 to 158° F)
Visual Display	12-inch monochrome CRT
Electrical Data	
Power Supply	Variable-voltage switch mode power supply 100 V – 240 V (– 15 to + 10%) Line frequency 48 to 62 Hz
Power Consumption	Approx. 31 W
Encoder Inputs	
Signal Amplitudes	For all HEIDENHAIN linear encoders with sinusoidal scanning signals, also with distance-coded reference marks
Permissible Input Frequency	7 to 16 μ A _{pp} Max. 100 kHz
Data Interface	
	RS-232-C/V.24, for measured values, programs and operating parameters 110/150/300/600/1200/2400/4800/9600/19200/38400 baud

Features	
Axes	Number: 4 Axes Choice of axis designations: A B C U V W X Y Z Combinations: X1 $\pm$ X4 or X2 $\pm$ X4 or X3 $\pm$ X4
Display Step/Signal Period	(see Technical Description, tables 1.3.1 and 1.3.2)
Modes of Operation	BASIC, EXPERT, PROGO
Program Memory	20 different programs or 2000 program blocks
Datum Points	Five independent datum points, selectable as desired via keyboard
Reference Mark Evaluation	For linear encoders with one, several or distance-coded reference marks. After a power interruption the relationship between the encoder position and the display value is lost; this relationship is quickly and easily re-established by crossing the reference points.
Functions	
	• Tool radius compensation • Distance-To-Go display (traversing to display value 0) • Bolt-hole circle with graphics • Radius/Diameter display in 4 axes • Probe functions for datum acquisition (workpiece edge, centerline or circle center) • mm/inch display • Scaling factor in 4 axes (0.100000 to 9.999999) • Linear machine error compensation $\pm$ (0 to 99999 μm/m)
Auxiliary Functions	• INFO: cutting data, pocket calculator functions, stopwatch • HELP: built-in operating instructions
External Functions	• Zero reset • Storage command • Signal output with display value of zero (zero recognition range: $\pm$ 99.999 mm)
Edge Finder	Connection of KT 110 (edge finder) or TS 120 (3D Touch Probe System) from HEIDENHAIN
Languages	2 languages can be selected (see section 1.4.2)

8 Dimensions




Front





Angle bracket with threaded bolt M5 x 20

Rear



External functions only
with versions -2, -3



Technisches Büro Baden-Württemberg

Eichachstraße 20
7404 Oeffdingen
(07473) 227 33
FAX (07473) 217 64

Technisches Büro Berlin

Kaisern-Augusta-Allee 86
W-1000 Berlin 10
(030) 345 20 65
FAX (030) 345 33 64

Technisches Büro Chemnitz

Crusiusstraße 4
O-9048 Chemnitz
(Chemnitz) 59 23 85
FAX (Chemnitz) 59 22 83

Technisches Büro Hamburg

Barnhoistraße 50
2000 Wedel
(04103) 74 38
FAX (04103) 162 03

Technisches Büro Hessen

Lindenweg 24
6479 Schotten 1
(06044) 29 95
FAX (06044) 33 49

Technisches Büro Nordbayern

Badstraße 21
8580 Bayreuth
(0921) 648 17
FAX (0921) 543 49

Technisches Büro Nordrhein-Westfalen

Siresemannstraße 12
5800 Hagen
(02331) 326 37
FAX (02331) 132 94

Technisches Büro Südbayern

Dr.-Johannes-Heidenhain-Straße 5
8225 Traunreut
(08669) 3113 45
FAX (08669) 50 61

■ Auslands-Vertretungen ■ Agences abroad ■ Agences étrangères

Belgien Belgium Belgique

HEIDENHAIN BELGIEN
Beltekouter, 30
B-1790 Affligem
(053) 67 25 70
FAX (053) 67 01 65

Brasilien Brazil Brésil

DIADUR Indústria e Comércio Ltda.
Rua Serva, 329 - Socorro, Santo Amaro
Post Box 12 695
04763 São Paulo - SP, Brasil
(011) 523 - 6777
FAX (011) 52314 11

Dänemark Denmark Danemark

TP TEKNIK A/S
Kobbelvænget 74
DK-2700 Brønshøj
(3889) 0166
FAX 3889 0165

Finland Finland Finlande

NC-POINT OY
Post Box 87
Suilante 7 D
SF-04300 Hyytiälä
(0) 25 94 00
FAX (0) 25 79 98

Frankreich France France

HEIDENHAIN FRANCE sarl
2, Avenue de la Cristallerie
Post Box 62
F-92312 Sèvres
(1) 45 34 61 21
FAX (1) 45 07 20 00

Griechenland Greece Grèce

D. PANAYOTIDIS - J. TSATSIS S.A.
6, Pireos St.
GR-183 46 Moschaton - Athens
(01) 48108 17
FAX (01) 48296 73

Großbritannien und Irland U.K. and Ireland

Angleterre et Irlande
HEIDENHAIN (G.B.) Limited
200 London Road, Burgess Hill
West Sussex RH15 9RD
(0444) 24 77 11
FAX (0444) 87 00 24

Indien India Inde

ASHOK & LAL
12 Pula Reddy Avenue
Post Box 5422
Madras - 600 030
(044) 6172 89
FAX (044) 6182 24

Israel

NEUMO VARGUS
34-36, Itzhak Sade St.
Post Box 20102
Tel-Aviv 61212
(3) 5373275
FAX (3) 5372190

Italien Italy Italie

HEIDENHAIN ITALIANA srl
Viale Misurata 16
I-20146 Milano
(02) 483002 41... 45
FAX (02) 47710730

Japan Japan Japon

HEIDENHAIN K.K.
Sogo-Daichi Bldg. 2 F
3-2, Kojimachi, Chiyoda-ku
Tokyo 102
(03) 3234 - 7781
FAX (03) 3262-2539

Kanada Canada

HEIDENHAIN CORPORATION
Canadian Regional Office
1075 Meyers Drive, Unit 5
Mississauga, Ontario L5T 1M3, Canada
(416) 670-8900
FAX (416) 670-4426

Korea

SEO CHANG CORPORATION LTD.
Rm. 903, Jeail Bldg. 44-35
Yoido-Dong, Yongsungpo-ku, Seoul
C.P.O. Box 9756 Seoul, Korea
(02) 7808208
FAX (02) 7845408

Mexico

HEIDENHAIN MEXICO S.L.
Calle San Juan de los Lagos 202
Frac. Jardines de la Concepción
CP 20120 Aguascalientes, Ags.
(491) 437 38
FAX (491) 437 38

Niederlande Netherlands : Pays-Bas

HEIDENHAIN NEDERLAND B.V.
Landlweel 20
Post Box 107
NL-3900 AC Veenendaal
(08385) 40300
FAX (08385) 17287

Norwegen Norway Norvège

KASKO MASKIN A/S
Post Box 3083
Haakon Vils. gt. 6
N-7003 Trondheim
(07) 919100
FAX (07) 913377

Österreich Austria Autriche

Alois Zollner
Dr.-Johannes-Heidenhain-Straße 5
D-8226 Traunreut
(08669) 3113 37
FAX (08669) 50 61

Portugal

FARRESA ELECTRONICA LTDA.
Rua Goncalo Cristovao 294 - 1º
P-4000 Porto
(2) 318440
FAX (2) 318044

Schweden Sweden Suède

A. KARLSON INSTRUMENT AB
Post Box 111
S-14501 Norsborg
(0753) 89350
FAX (0753) 84518

Schweiz Switzerland Suisse

HEIDENHAIN (SCHWEIZ) AG
Post Box
Verstasse 14
CH-8603 Schwenenbach
(01) 8250440
FAX (01) 8253346

Singapur Singapore Singapour

HEIDENHAIN PACIFIC PTE LTD
50, Lorong 21, Geylang
Singapore, 1438
(432) 38
FAX 7493922

Spanien Spain Espagne

FARRESA ELECTRONICA S. A.
c/ Simon Bolivar, 27 - Dpto. 11
E-48013 Bilbao (Vizcaya)
(94) 4413649
FAX (94) 4423540

Taiwan

MINTKE SUPPLY CO. LTD.
1F, 256-3 Lung Chiang Road, Taipei, 10481
Republic of China
(02) 5034375
FAX (02) 5050108

Tschechoslowakei Czechoslovakia Tchecoslovaquie

HEIDENHAIN
Technická Kancelář ČSFR
Samcová 1
CS-11000 Praha 1
(02) 2310509
FAX (02) 2310551

Türkei Turkey Turquie

ORSEL LTD.
Kusdili Cad. No. 43
Toraman Han, Kat 3
TR-81310 Kadikoy/Istanbul
(1) 3478395
FAX (1) 3478393

Ungarn Hungary Hongrie

HEIDENHAIN
Magyarországi Kereskedelmi Képviselet
Mészaki tódá
Dunyov István utca 16.
H-1134 Budapest
(1) 1202213
FAX (1) 1202213

USA

HEIDENHAIN CORPORATION
115 Commerce Drive
Schaumburg, IL 60173
(708) 490-1191
FAX (708) 490-3931